

# TS-22-QS/短柄照光選擇開關



## 作動模式



Selector Head  
2positions 0-I or I-II  
switching angle 90°  
do.but illuminated version

ON-OFF  
ON-ON  
2 段選擇

- TS-22-QS-1R
- TS-22-QS-1G
- TS-22-QS-1Y
- TS-22-QS-1W
- TS-22-QS-1BL

- TS-22-QS-2R
- TS-22-QS-2G
- TS-22-QS-2Y
- TS-22-QS-2W
- TS-22-QS-2BL

ON-OFF-ON  
3 段選擇

Selector Head  
3positions I-0-II or 0-I-II  
switching angle 45° + 45°  
do.but illuminated version

## 作動模式



## 作動模式



Selector Head(spring reset)  
switching position on the left.  
with spring reset to 0-position  
from the right.I-0-II  
switching angle 45° + 45°  
do.but illuminated version

ON-OFF-ON  
3 段單邊彈回


- TS-22-QS-3R
- TS-22-QS-3G
- TS-22-QS-3Y
- TS-22-QS-3W
- TS-22-QS-3BL

- TS-22-QS-4R
- TS-22-QS-4G
- TS-22-QS-4Y
- TS-22-QS-4W
- TS-22-QS-4BL

ON-OFF  
ON-ON  
2 段單邊彈回

Selector Head(spring reset)  
with spring reset to 0-position  
(on the left).0-I  
switching angle 90°  
do.but illuminated version

## 作動模式



## 作動模式



Selector Head(spring reset)  
with spring reset to the middle  
position I→0←II  
switching angle 45° + 45°  
do.but illuminated version

ON-OFF-ON  
3 段雙邊彈回

- TS-22-QS-5R
- TS-22-QS-5G
- TS-22-QS-5Y
- TS-22-QS-5W
- TS-22-QS-5BL